


11510 Goldcoast Drive • Cincinnati, OH, USA 45249-1621
(513) 671-3322 • FAX (513) 671-3363 • E-mail: techhelp@exair.com

Capacitor



The Model 4519 Capacitor prevents thermostat contact bounce and solenoid chatter due to small switching loads. Wire this capacitor in parallel (across the leads) of the Model 9017 Thermostat. The capacitor is rated .002 Microfarad, 250 VAC, 50/60 Hz.

Model 9017 Thermostat is preset at 95°F (35°C). One quarter turn of the slotted adjusting screw will change the thermostat setting by approximately 25°F (14°C).

Caution: Do not remove adjusting screw or turn adjusting screw in too far. This can permanently damage the thermostat.

If you have any questions or problems, please contact an EXAIR Application Engineer at:

Toll Free: 1-800-903-9247 (U.S. & Canada)

Telephone: 513 671-3322 outside of U.S. & Canada

Toll Free Fax: 866-329-3924 (U.S. & Canada)

FAX: 513 671-3363 outside of U.S. & Canada

E-mail: techhelp@exair.com

Website: www.exair.com

